



## Journey Suspension Lowrider and Lowrider Racks

### Before You Start:

#### Package contents:

- quick release skewer
- 10 mm nuts
- 10 mm capped nuts
- rubberizer mounting plates
- rubberized “U” clamps
- spacers
- left and right Odyssee suspension rack assembly

#### Tools required:

- 10mm Allen key

### Mounting Instructions:

#### Prepare the rack for mounting:

1. Unscrew and remove the nut and one spring of the provided quick release skewer.
2. Slide the quick release skewer into left rack assembly (there is an L stamped on the left side).

**Note:** You may be wondering which end of the rack is the front. The front of the rack is the end with the mounting hole. Check out the picture.

3. Remove the quick release skewer from the front wheel axle of your bicycle.

#### Mount the lower part of the rack:

4. Insert the new quick release skewer with the left rack assembly into the left side (looking from the back of your bicycle) of your fork and axle of your bicycle.
5. Slide the right side rack assembly and the skewer spring onto the skewer and thread the quick release nut onto the skewer.



6. Tighten and close the quick release skewer. The rack should still be able to move towards the front and back.

**Install the upper part of the rack:**

7. Slide a "U" clamp onto the fork so the threaded ends are pointing away from the bicycle and are through the holes in the mounting plate of the rack.
8. Thread an open nut onto each threaded end of the "U" clamp.
9. Place a capped nut on each threaded end of the "U" clamp. (Use a 10mm wrench).
10. Repeat steps 7 to 9 on the other side of the fork.

**Tighten and go for a ride:**

11. Ensure both sides of the rack are set to an equal height and angle.
12. Tighten all bolts and make sure the rack is secure.
13. Add panniers and go for a ride!
14. Visit [www.axiomgear.com](http://www.axiomgear.com) and let us know what you are up to, post your pictures, review our products and tell us how we made your ride a better one!